



# BW16 Datasheet

## Version V1.2 Copyright ©2019

Copyright © 2019 Shenzhen Ai-Thinker Technology Co., Ltd All Rights Reserved



### **Disclaimer and copyright notice**

The information in this article, including the URL address for reference, is subject to change without prior notice. The Documentation is provided "as is" without any warranty, including any warranties of merchantability, fitness for a particular purpose, or non-infringement, and any warranties mentioned in the proposal, specification or sample. This document is not responsible for any infringement of any patent rights arising out of the use of the information in this document. No license, express or implied, by estoppel or otherwise, is hereby granted.

The test data obtained in this paper are all obtained by Ai-Thinker laboratory, and the actual results may be slightly different. The Wi-Fi alliance membership mark is owned by the WiFi alliance.

All trade mark names, trademarks and registered trademarks mentioned herein are the property of their respective owners and are hereby declared.

The final interpretation right is owned by Shenzhen Ai-Thinker Technology Co., Ltd.

#### Note

The contents of this manual may be changed due to the version upgrade of the product or other reasons. Shenzhen Ai-Thinker Technology Co., Ltd. reserves the right to modify the contents of this manual without any notice. This manual is only used as a guide, and Shenzhen Ai-Thinker Technology Co., Ltd. makes every effort to provide accurate information in this manual, but Shenzhen Ai-Thinker Technology Co., Ltd. does not ensure that the contents of the manual are completely true,, All statements and information in this manual. and the recommendations do not constitute for any warranty, express or implied.



## **Change History of Revision**

Versio n	Date	Contents of Revision Change	Compilation	Verify
V0.9	2019.06.15	Initial release	Yang Xiaofei	Hong Xu
V1.0	2019.10.29	Updated	Xie Yiji	Hong Xu
V1.1	2021.02.05	Updated flash	Xie Yiji	Hong Xu
V1.2	2023.08.30	Updated temperature picture	Li xiaocheng	Hong Xu




মি
1~1~

I . Product overview	5
II. Electrical parameter	7
III. Appearance size	
IV. Pin definition	9
V. Schematics	
VI. Design Guidance	
VII. ROLLING OF Reflow soldering	14
VIII. Package Information	
IX. Contacts	15



#### I . Product overview

BW16 is a dual-frequency Wi-Fi Bluetooth SoC module based on RTL8720DN. BW16 supports dual-frequency (2.4ghz or 5ghz) WLAN and low-power Bluetooth 5.0; it integrates ARM V8 (compatible with Cortex-M4F) high-performance MCU, ARM V8M (compatible with Cortex-M0) low-power MCU, WLAN(802.11 a / b / g / n), MAC, Bluetooth baseband and RF baseband) and provides a set of configurable GPIO ports for the control of different peripherals.



## **Features**

- Support 802. 11a/b/g/n 1x1 , 2.4GHz or 5GHz.
- Support HT20/HT40 mode .
- Support for low power beacon listening mode, low power reception mode and low power pending mode.
- Embedded AES / DES / SHA hardware engine.
- Support TrustZone-M and safed start up.



- Support SWD debug port access protection and prohibition mode.
- Support BLE5.0
- Bluetooth supports high power mode (7dBm, share the same PA with WiFi)
- Wi-Fi and BT share the same antenna.
- Support STA/AP/STA+AP operating mode

■ Support the Smart Config (APP) /AirKiss(wechat) of Android 、 IOS (One-click distribution network

■ Support serial port local upgrade and remote firmware upgrade (FOTA)

#### **Parameters**

Figure 1 Main Parameter			
Model BW16			
Package	SMD-16		
Size 24*16*3(±0.2)MM			
Antenna PCB or IPEX antenna			
Frequency range	2400-2483.5MHz or 5180-5825MHz		
Bluetooth BLE 5.0			
Bluetooth frequency range 2.402GHz - 2.480GHz			
Operating temperature	$-40$ °C $\sim$ 85 °C		
Storage Environment	-40 °C $^{\sim}$ 125 °C , < 90%RH		
Power supply	Voltage 3.0V $^{\sim}$ 3.6V, Typ:3.3V, current >450mA		
Interface	UART/GPIO/ADC/PWM/IIC/SPI/SWD		
Certification	RoHS、FCC、CE、SRRC		
FLASH	Default 16Mbit (Support 16Mbit/32Mbit/64Mibt/128Mbit)		



#### **II. Electrical parameter**

#### Noted:

BW16 module is an electrostatic sensitive device, which needs special ESD precautions. When usd ESD protective devices should be added. The correct ESD processing and packaging must be adopted in the transportation, operation and use of BW16 modules. Do nottouch the module by hand or weld with a non-antistatic soldering iron to avoid damage to the module.

Parameter	Min	Тур	Max	Unit
DC 3.3V (with internal regulator and integration CMOS PA)	3.0	3. 3	3.6	V
Figure I/O supply voltage	1.76	1.8-3.3	3.3	mA
DC_I0_33 (3.3V I / 0 rated current)			50	mA
Electrostatic protection (VESD)			2000	V

## **Radio Performance**

Description	Тур	Unit	
Operating frequency	2400–2483.5 or 5180–5825	MHz	
	Output Power		
11a mode, PA output power	$14 \pm 2$	dBm	
11n mode, PA output power	$14 \pm 2$	dBm	
11g mode, PA output power	$15 \pm 2$	dBm	
11b mode, PA output power	$16 \pm 2$	dBm	
Bluetooth output power	$7\pm 2$	dBm	
Sensitivity			
CCK, 1 Mbps	<=-90	dBm	
CCK, 11 Mbps	<=-85	dBm	
6 Mbps (1/2 BPSK)	<=-88	dBm	


Copyright © 2019 Shenzhen Ai-Thinker Technology Co., Ltd All Rights Reserved


第7页共14页



54 Mbps (3/4 64-QAM)	<=-70	dBm
HT20 (MCS7)	<=-67	dBm
Bluetooth Sensitivity	<=-92	dBm

## III. Appearance size







## **IV. Pin definition**

BW16 has 16 interface, refer to following Pin diagram , table 2.2 is definition of interfaces.




BW16 Pin diagram

No.	Name	Function
1	PA13	LP_PWM1/SPI1_MISO
2	PB3	ADC/SWD_CLK
3	CHIP_EN	Chip enable port
4	PA15	SPI1_CS
5	PA8	UART_LOG_RXD
6	PA27	SWD_DATA
7	PA26	LP_I2C_SDA/LP_PWM5
8	VDD_3V3	3.3V (VDD) ; Max: 450mA
9	GND	Ground
10	PA25	LP_I2C_SCL/LP_PWM4
11	PA7	UART_LOG_TXD
12	PA14	SPI1_CLK
13	PA30	LP_PWM1
14	PA12	SPI1_MOSI/LP_PWMO
15	PB2	LP_UART_RXD
16	PB1	LP_UART_TXD

Copyright © 2019 Shenzhen Ai-Thinker Technology Co., Ltd All Rights Reserved




#### **V. Schematics**



## **VI.** Design Guidance


1、Application Circuit



Copyright © 2019 Shenzhen Ai-Thinker Technology Co., Ltd All Rights Reserved



#### 2、Dimension




#### 3. Antenna layout requirements

(1) 、Installation position on the main board, advise for following two ways: Option 1: The module is placed on the edge of the main board, and the antenna area is extended out of the edge of the main board.

Option 2: Put the module on the edge of the motherboard, and the edge of the motherboard is hollowed out in the antenna position.

(2) . In order to meet the performance of the on-board antenna, metal parts are prohibited from being placed around the antenna.



#### 4. Power Supply

 ${\it C}$ opyright © 2019 Shenzhen Ai-Thinker Technology Co., Ltd All Rights Reserved




(1) Recommended voltage 5V, Peak:Current over 500mA.

(2) It is recommended to use the LDO power supply; If DC-DC is used, the ripple is controlled within 30 mV.

(3) , DC-DC power supply circuit is recommended to reserve the position of the dynamic response capacitor, and the output ripple can be optimized when the load change is large.

(4) Proposed addition of ESD Devices to 5V Power supply Interface.




#### 5、GPIO

(1) At the periphery of the module, some GPIO ports are led out, and a resistance of 10-100 ohms can be connected in series on the IO port for use. This suppresses overshoot and is more stable on both sides. Help for both EMI and ESD.

(2) For the up-and-down drawing of the special io-port, reference will be made to the use description of the specification, which will affect the start-up configuration of the module.

(3) The IO port of the module is 3.3 v. If the main control does not match the io-level of the module, it is necessary to increase the level conversion circuit.(4) If the IO interface is directly connected to the peripheral interface, or the pins and other terminals, it is recommended to reserve the ESD device near the terminal at the IO trace.






Level switching circuit









#### VIII. Package Information

As shown below, the packing of BW16 is a tape.



#### **IX.** Contacts

Company website: <u>https://www.ai-thinker.com</u> Developer Wiki: <u>http://wiki.ai-thinker.com</u> Company forum: <u>http://bbs.ai-thinker.com</u> Sampling purchasing: <u>https://anxinke.taobao.com</u> Business cooperation: <u>sales@aithinker.com</u> Technology support: <a href="mailto:support@aithinker.com">support@aithinker.com</a>



Company address: Room410, Building C, Huafeng Intelligence Innovation Port,

Gushu, Xixiang, Baoan District, Shenzhen China 518126