


How to re edit product SDK capabilities?

To edit an already generated product, click on the product list

1、 In the product list, select the product that needs to be edited and click to view details



2、 Enter the product details page, in the version number list on the right, select the version you want to edit, and click Edit

[Create Product](#)

	module	creation time	operation
	VC-01	2022-09-01 17:24:58	view detail delete
	VC-02	2022-08-19 15:07:44	view detail delete
	VC-02	2022-08-04 08:52:23	view detail delete
	VC-02	2022-08-03 09:38:57	view detail delete
	VC-02	2022-08-02 17:44:39	view detail delete
	VC-02	2022-07-21 14:58:16	view detail delete
	VC-02	2022-07-19 11:01:27	view detail delete
	VC-02	2022-07-18 16:52:36	view detail delete
	VC-02	2022-07-11 08:58:49	view detail delete
	VC-02	2022-07-06 08:38:26	view detail delete

Create Product



version number	version description	creation time	SDK status	operation
20220913001	1	2022-09-13 11:34:59	built	edit download SDK delete download firmware

3、 Go to the edit page of this version and reset the SDK capabilities.

**front-end signal processing**

Device microphone configuration, packaged SDK optimizes the signal according to different microphone conditions, so that the device can recognize the voice more accurately

Microphone <input checked="" type="radio"/> single MIC <input type="radio"/> double MIC	distance <input type="radio"/> Near field 0-1m <input checked="" type="radio"/> Far field 1-5m
configuration	recognition
AEC echo <input checked="" type="radio"/> close <input type="radio"/> open	Steady-state <input type="radio"/> close <input checked="" type="radio"/> open
cancellation	noise reduction

Pin configuration

Through customization, code can be automatically generated, and ports such as GPIO, PWM, and UART can output custom signals according to voice commands, and external devices can be controlled without code development.

Pin No.	Function	parameter 1	parameter 2	parameter 3	parameter 4	Remark
1	SW_CLK					Burning function, after configuring other functions, you cannot use the burner to download firm

4、 After setting, click "Generate New Version".



make new version

5、 In the version list, select the new version, regenerate the SDK and download it.



version number	version description	creation time	SDK status	operation
20221010001		2022-10-10 17:21:48		 edit build SDK delete